

Instructions for Agricultural dispensing of PAM 25™

Perform the jar test first to determine the proper (ppm) rate of PAM 25™ to be installed into the water flow.

Place the dispensing system and product container(s) at the entrance to the head ditch before opening the flood gate.

Once the rate has been determined, meter PAM 25™ into the water flow until the entire field has been irrigated, then halt the installation process.

The approximate quantity of PAM 25™ to be installed is one (1) gallon per 2.75 row acres.